



Boeing Applications Parts List

AIRCRAFT MFG	Aircraft	BOEING PT. NO.	Rogerson Kratos PT. NO.	Flightline PT. NO.	DESCRIPTION	-100	-200	-300	-400	-500	-600	-700	-800	-900
BOEING	737	S231N212-6	124-838	147LC10	INDICATOR, CSD OIL TEMP	X								
BOEING	737	S231N212-2	124-834	149LA6	INDICATOR, DC AMP	X	X	X	X	X				
BOEING	737	S231N212-1	124-837	149LA7	INDICATOR, AC AMPS	X	X	X	X	X				
BOEING	737	S231N212-5	124-835	149LF10	INDICATOR, FREQUENCY	X	X	X	X	X				
BOEING	737	S231N212-3	124-832	149LV11	INDICATOR, AC VOLTS	X	X	X	X	X				
BOEING	737	S231N212-4	124-833	149LV8	INDICATOR, D.C.VOLTS	X	X	X	X	X				
BOEING	737	10-62190-1		152LMA18	INDICATOR, EGT 2" RND			X	X	X				
BOEING	737	10-62190-2		152LMA22	INDICATOR, EGT 2" RND									
BOEING	737	10-62190-3		152LMA23	INDICATOR, EGT 2" RND			X	X	X	X	X	X	X
BOEING	737	6502-11KA		153400-1	6502-11KA, ALT SWITCH									
BOEING	737	6502-16K		153400-2	6502-16K, ALTITUDE SWITCH									
BOEING	737	S231N212-7	114-029	154LUA104	INDICATOR, VALVE POS	X	X	X	X	X	X	X	X	X
BOEING	737	10-60521-2		162BL801	INDICATOR, TEMP ELECT RES						X	X	X	X
BOEING	737	162BL902		162BL902	INDICATOR, RES.TEMP.						X	X	X	X
BOEING	737	162BL903		162BL903	INDICATOR, RES.TEMP.						X	X	X	X
BOEING	737	S417N207-7		163CV59	INDICATOR, WATER QTY						X	X	X	X
BOEING	737	S417N207-8		163CV64	INDICATOR, WASTE QTY						X	X	X	X
BOEING	737	S231W210-2		163LCP80	INDICATOR, BRAKE PRESS						X	X	X	X

AIRCRAFT MFG	Aircraft	BOEING PT. NO.		Flightline PT. NO.	DESCRIPTION	-100	-200	-300	-400					
BOEING	747	6502-11KA		153400-1	6502-11KA, ALT SWITCH	X	X	X						
BOEING	747	6502-10K		153400-13	6502-10K, ALT SWITCH				X					
BOEING	747	6502-21K		153400-4	6502-21K, ALTITUDE SWITCH		X	X						
BOEING	747	6502-23K		153400-5	6502-23K, ALTITUDE SWITCH		X	X						
BOEING	747	6502-6K		153400-7	6502-6K, ALTITUDE SWITCH	X	X	X						
BOEING	747	6510		153847-1	6510, AIRSPEED SWITCH				X					
BOEING	747	6522		153847-2	6522, AIRSPEED SWITCH		X	X						
BOEING	747	6501		153847-8	6501, AIRSPEED SWITCH	X	X	X						
BOEING	747	S271U123-2	50483-35	162LCP639	INDICATOR, HYD. BRAKE PRESS									
BOEING	747	71505-54B		71505-54B	INDICATOR, WATER QTY				X					

AIRCRAFT MFG	Aircraft	BOEING PT. NO.		Flightline PT. NO.	DESCRIPTION	-100	-200	-300						
BOEING	757	6502-10K		153400-13	6502-10K, ALT SWITCH		X	X						
BOEING	757	6510		153847-1	6510, AIRSPEED SWITCH		X	X						
BOEING	757	S417N207-1	115-161	163CV57	INDICATOR, WATER QTY		X							
BOEING	757	S417N207-2	115-217	163CV58	INDICATOR, WATER QTY		X							
BOEING	757	S417N207-3	115-160	163CV60	INDICATOR, WATER QTY		X							
BOEING	757	S417N207-4	115-216	163CV61	INDICATOR, WATER QTY		X							
BOEING	757	S417N207-5	115A-160-2	163CV62	INDICATOR, WATER QTY		X							
BOEING	757	S417N207-6	115A-216-2	163CV63	INDICATOR, WATER QTY		X							
BOEING	757	S417N207-12		163CV65	INDICATOR, WATER QTY				X					
BOEING	757	S417N207-9		163CV66	INDICATOR, WATER QTY				X					
BOEING	757	S417N207-13		163CV67	INDICATOR, Waste QTY				X					
BOEING	757	S231N212-9	115-099-9	163LCP77	INDICATOR, BRAKE PRESS				X					

AIRCRAFT MFG	Aircraft	BOEING PT. NO.		Flightline PT. NO.	DESCRIPTION	-100	-200	-300	-400					
BOEING	767	6502-10K		153400-13	6502-10K, ALT SWITCH		X	X	X					
BOEING	767	6502-16K		153400-2	6502-16K, ALTITUDE SWITCH		X	X						
BOEING	767	6502-21K		153400-4	6502-21K, ALTITUDE SWITCH		X	X						
BOEING	767	6510		153847-1	6510, AIRSPEED SWITCH		X	X	X					
BOEING	767	S231N212-8	114-174	154LUA105	INDICATOR, VALUE POS		X		X					
BOEING	767	S231N212-11	115-112	163LCP76	INDICATOR, OXYGEN PRESS				X					
BOEING	767	S231N212-10	115-099-8	163LCP78	INDICATOR, BRAKE PRESS				X					

AIRCRAFT MFG	Aircraft	BOEING PT. NO.		Flightline PT. NO.	DESCRIPTION	-100	-200	-300						
BOEING	777	S231W210-1		163LCP74	INDICATOR, BRAKE PRESS	X	X	X						